



# Illustrated Parts List

## Model Series

# 10T700

TYPE NUMBERS  
0113 through 3857.

### TABLE OF CONTENTS

|                                   |   |
|-----------------------------------|---|
| Air Cleaner .....                 | 5 |
| Blower Housing/Shrouds .....      | 6 |
| Brake .....                       | 5 |
| Camshaft .....                    | 3 |
| Carburetor .....                  | 4 |
| Controls .....                    | 5 |
| Crankcase Cover/Sump .....        | 3 |
| Crankshaft .....                  | 3 |
| Cylinder .....                    | 2 |
| Cylinder Head .....               | 2 |
| Exhaust System .....              | 5 |
| Flywheel .....                    | 6 |
| Fuel Supply .....                 | 4 |
| Gasket Set - Engine .....         | 2 |
| Gasket Set - Valve .....          | 2 |
| Governor Spring .....             | 5 |
| Ignition .....                    | 5 |
| Lubrication .....                 | 2 |
| Operator's Manual .....           | 2 |
| Piston/Rings/Connecting Rod ..... | 3 |
| Rewind Starter .....              | 6 |
| Warning Label .....               | 2 |




PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION  
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

# 10T700

1058 OPERATOR'S MANUAL



1330 REPAIR MANUAL




1319 WARNING LABEL




|                |                                                                                  |
|----------------|----------------------------------------------------------------------------------|
| <b>WARNING</b> |                                                                                  |
|                | Read and follow Operating Instructions before running engine.                    |
|                | Gasoline is flammable. Allow engine to cool at least 2 minutes before refueling. |
|                | Engines emit carbon monoxide, DO NOT run in enclosed area.                       |
|                | Muffler area temperature may exceed 150°F. Do not touch hot parts.               |

**REQUIRED** when replacing parts with warning labels affixed.


358 ENGINE GASKET SET






1095 VALVE GASKET SET



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 3756-2 Assemblies include all parts shown in frames. 07/13/2010












Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
 3756-5 Assemblies include all parts shown in frames. 07/13/2010

1036 EMISSIONS LABEL



| REF. NO. | PART NO. | DESCRIPTION                                                                                                                    | REF. NO. | PART NO. | DESCRIPTION                                                                                                                                                 | REF. NO. | PART NO. | DESCRIPTION                                                                                                             |
|----------|----------|--------------------------------------------------------------------------------------------------------------------------------|----------|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|-------------------------------------------------------------------------------------------------------------------------|
| 1        | 699653   | Cylinder Assembly                                                                                                              | 25       | 795691   | Piston Assembly (Standard)                                                                                                                                  | 60       | 691915   | Grip-Starter Rope                                                                                                       |
| 2        | 796961   | Kit-Bushing/Seal (Magneto Side)                                                                                                |          |          | ----- Note -----                                                                                                                                            | 65       | 690837   | Screw (Rewind Starter)                                                                                                  |
| 3        | 299819S  | Seal-Oil (Magneto Side)                                                                                                        |          |          | 795689 Piston Assembly (.020" Oversize)                                                                                                                     | 73       | 699850   | Screen-Rotating                                                                                                         |
| 4        | 798264   | Sump-Engine                                                                                                                    |          |          |                                                                                                                                                             | 78       | 692198   | Screw (Flywheel Guard)                                                                                                  |
| 5        | 790169   | Head-Cylinder                                                                                                                  | 26       | 795690   | Ring Set (Standard)                                                                                                                                         | 81       | 691179   | Lock-Muffler Screw Used on Type No(s). 0117, 0870, 0934, 0944, 1074.                                                    |
| 7        | 698717   | Gasket-Cylinder Head                                                                                                           |          |          | ----- Note -----                                                                                                                                            |          |          |                                                                                                                         |
| 8        | 791781   | Breather Assembly                                                                                                              |          |          | 795688 Ring Set (.020" Oversize)                                                                                                                            | 90       | 795477   | Carburetor                                                                                                              |
| 9        | 695890   | Gasket-Breather                                                                                                                | 27       | 691588   | Lock-Piston Pin                                                                                                                                             | 97       | 691931   | Shaft-Throttle                                                                                                          |
| 10       | 691666   | Screw (Breather Assembly)                                                                                                      | 28       | 699659   | Pin-Piston                                                                                                                                                  | 106      | 691901   | Seat-Inlet                                                                                                              |
| 11       | 691245   | Tube-Breather                                                                                                                  | 29       | 699654   | Rod-Connecting                                                                                                                                              | 130      | 691190   | Valve-Throttle                                                                                                          |
| 12       | 692218   | Gasket-Crankcase (Standard) (.015" Thick)                                                                                      | 32       | 691664   | Screw (Connecting Rod)                                                                                                                                      | 163      | 271139S  | Gasket-Air Cleaner                                                                                                      |
| 13       | 691640   | Screw (Cylinder Head)                                                                                                          | 33       | 296676   | Valve-Exhaust                                                                                                                                               | 180      | 494406   | Tank-Fuel                                                                                                               |
| 15       | 691680   | Plug-Oil Drain                                                                                                                 | 34       | 296677   | Valve-Intake                                                                                                                                                | 188      | 692198   | Screw (Control Bracket)                                                                                                 |
| 16       | 796217   | Crankshaft Used on Type No(s). 0123, 0130, 0498, 0735, 0808, 0843, 0857, 0870, 0874, 0934, 0944, 1074, 3735, 3808, 3843, 3857. | 35       | 690520   | Spring-Valve (Intake)                                                                                                                                       | 190      | 691640   | Screw (Fuel Tank) (1 3/4" Long)                                                                                         |
|          |          | ----- Note -----                                                                                                               | 36       | 690520   | Spring-Valve (Exhaust)                                                                                                                                      | 190A     | 691108   | Screw (Fuel Tank) (9/16" Long)                                                                                          |
|          |          | 796216 Crankshaft Used on Type No(s). 0117, 0124, 0127, 0131.                                                                  | 37       | 691209   | Guard-Flywheel (Muffler Side)                                                                                                                               | 200      | 691912   | Blade-Governor                                                                                                          |
|          |          | 796218 Crankshaft Used on Type No(s). 0113, 0114.                                                                              | 37A      | 690482   | Guard-Flywheel (Carburetor Side)                                                                                                                            | 201      | 690347   | Link-Air Vane                                                                                                           |
| 20       | 391483S  | Seal-Oil (PTO Side)                                                                                                            | 40       | 692194   | Retainer-Valve                                                                                                                                              | 209      | 690251   | Spring-Governor Used on Type No(s). 0117, 0735, 0808, 0843, 0857, 0870, 0874, 0934, 0944, 1074, 3735, 3808, 3843, 3857. |
| 22       | 692551   | Screw (Crankcase Cover/Sump)                                                                                                   | 43       | 698690   | Slinger-Governor/Oil                                                                                                                                        |          |          | ----- Note -----                                                                                                        |
| 23       | 795549   | Flywheel                                                                                                                       | 45       | 691762   | Tappet-Valve                                                                                                                                                |          |          | 691297 Spring-Governor Used on Type No(s). 0113, 0130, 0131, 0498.                                                      |
|          |          | ----- Note -----                                                                                                               | 46       | 691998   | Camshaft                                                                                                                                                    |          |          | 691862 Spring-Governor Used on Type No(s). 0114, 0123, 0124, 0127.                                                      |
|          |          | 795695 Flywheel Used on Type No(s). 0114, 0123, 0124, 0127.                                                                    | 50       | 699644   | Manifold-Intake                                                                                                                                             | 211      | 691859   | Spring-Governed Idle                                                                                                    |
| 24       | 222698S  | Key-Flywheel                                                                                                                   | 50A      | 792388   | Manifold-Intake                                                                                                                                             | 222E     | 691446   | Bracket-Control                                                                                                         |
|          |          |                                                                                                                                | 51       | 699649   | Gasket-Intake                                                                                                                                               | 222F     | 691445   | Bracket-Control Used on Type No(s). 0114, 0117, 0123, 0124, 0127.                                                       |
|          |          |                                                                                                                                | 51C      | 792389   | Gasket-Intake                                                                                                                                               |          |          |                                                                                                                         |
|          |          |                                                                                                                                | 54       | 691111   | Screw (Intake Manifold)                                                                                                                                     |          |          |                                                                                                                         |
|          |          |                                                                                                                                | 55       | 692144   | Housing-Rewind Starter                                                                                                                                      |          |          |                                                                                                                         |
|          |          |                                                                                                                                | 58       | 697316   | Rope-Starter (88 5/8" Long) Used on Type No(s). 0113, 0117, 0130, 0131, 0498, 0735, 0808, 0843, 0857, 0870, 0874, 0934, 0944, 1074, 3735, 3808, 3843, 3857. |          |          |                                                                                                                         |
|          |          |                                                                                                                                |          |          | ----- Note -----                                                                                                                                            |          |          |                                                                                                                         |
|          |          |                                                                                                                                |          |          | 691921 Rope-Starter (70" Long) Used on Type No(s). 0114, 0123, 0124, 0127.                                                                                  |          |          |                                                                                                                         |

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
3756-7 Assemblies include all parts shown in frames. 07/13/2010

# 10T700

| REF. NO. | PART NO. | DESCRIPTION                                                                                                                                                               | REF. NO. | PART NO. | DESCRIPTION                                                                                                                                | REF. NO.                                                                                                   | PART NO. | DESCRIPTION                                                                                                                                                         |
|----------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|--------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------|----------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 265A     | 690798   | Clamp-Casing<br>Used on Type No(s).<br>0127.                                                                                                                              | 333      | 793281   | Armature-Magneto<br>Used on Type No(s).<br>0113, 0117, 0124,<br>0130, 0131, 0498,<br>0735, 0808, 0857,<br>0870, 0934, 3735,<br>3808, 3857. | 459                                                                                                        | 281505S  | Pawl-Ratchet                                                                                                                                                        |
| 265B     | 691024   | Clamp-Casing<br>Used on Type No(s).<br>0117.                                                                                                                              |          |          |                                                                                                                                            | 523                                                                                                        | 692040   | Dipstick                                                                                                                                                            |
| 267      | 691044   | Screw<br>(Casing Clamp)                                                                                                                                                   |          |          |                                                                                                                                            | 524                                                                                                        | 691876   | Seal-Dipstick Tube                                                                                                                                                  |
| 268      | 691025   | Casing-Control Wire<br>(Cut To Required<br>Length)                                                                                                                        | 333B     | 793352   | Armature-Magneto<br>Used on Type No(s).<br>0114, 0123, 0127,<br>0843, 0874, 0944,<br>1074, 3843.                                           | 525                                                                                                        | 691320   | Tube-Dipstick                                                                                                                                                       |
| 269      | 691026   | Wire-Control<br>(Cut To Required<br>Length)                                                                                                                               | 334      | 691061   | Screw<br>(Magneto Armature)<br>(1" Long)                                                                                                   | 529                                                                                                        | 692189   | Grommet                                                                                                                                                             |
| 270      | 691027   | Nut<br>(Control Wire Casing)                                                                                                                                              | 335      | 691107   | Screw<br>(Magneto Armature<br>With Air Vane)<br>(1 15/16" Long)                                                                            | 534                                                                                                        | 691417   | Screw<br>(Air Cleaner)                                                                                                                                              |
| 271      | 691028   | Lever-Control                                                                                                                                                             |          |          |                                                                                                                                            | 535                                                                                                        | 698369   | Filter-Air Cleaner<br>Foam                                                                                                                                          |
| 287      | 691002   | Screw<br>(Dipstick Tube)                                                                                                                                                  | 337      | 796112S  | Plug-Spark<br>----- Note -----<br>697451 Plug-Spark<br>Used on Type No(s).<br>0117.                                                        | 536                                                                                                        | 698472   | Cleaner-Air                                                                                                                                                         |
| 300      | 692307   | Muffler<br>(Super Lo Tone)<br>Used on Type No(s).<br>0117, 0870, 0934,<br>0944, 1074.                                                                                     | 346      | 690661   | Screw<br>(Spark Arrester)<br>Used on Type No(s).<br>1074.                                                                                  | 592                                                                                                        | 690800   | Nut<br>(Rewind Starter)                                                                                                                                             |
| 300A     | 394569S  | Muffler<br>(Round Lo Tone)<br>Used on Type No(s).<br>0113, 0114, 0123,<br>0124, 0127, 0130,<br>0131, 0498, 0735,<br>0808, 0843, 0857,<br>0874, 3735, 3808,<br>3843, 3857. | 356      | 692390   | Wire-Stop                                                                                                                                  | 597                                                                                                        | 691696   | Screw<br>(Pawl Friction Plate)                                                                                                                                      |
| 304      | 694236   | Housing-Blower<br>----- Note -----<br>694051 Housing-<br>Blower<br>Used on Type No(s).<br>0114, 0117, 0123,<br>0124, 0127.                                                | 358      | 794209   | Gasket Set-Engine                                                                                                                          | 608                                                                                                        | 499706   | Starter-Rewind<br>Used on Type No(s).<br>0113, 0117, 0130,<br>0131, 0498, 0735,<br>0808, 0843, 0857,<br>0870, 0874, 0934,<br>0944, 1074, 3735,<br>3808, 3843, 3857. |
| 305      | 692198   | Screw<br>(Blower Housing)                                                                                                                                                 | 362      | 793351   | Shield-Spark Plug<br>Used on Type No(s).<br>0114, 0123, 0127,<br>0843, 0874, 0944,<br>1074, 3843.                                          | ----- Note -----<br>690101 Starter-Rope<br>(70" Rope)<br>Used on Type No(s).<br>0114, 0123, 0124,<br>0127. |          |                                                                                                                                                                     |
| 306      | 690400   | Shield-Cylinder                                                                                                                                                           | 363      | 19069    | Puller-Flywheel                                                                                                                            | 612                                                                                                        | 496046S  | Tube-Pick Up                                                                                                                                                        |
| 307      | 690345   | Screw<br>(Cylinder Shield)                                                                                                                                                | 365      | 790029   | Screw<br>(Carburetor)                                                                                                                      | 613                                                                                                        | 691413   | Screw<br>(Muffler)<br>Used on Type No(s).<br>0117, 0870, 0934,<br>0944, 1074.                                                                                       |
| 332      | 690662   | Nut<br>(Flywheel)                                                                                                                                                         | 383      | 89838S   | Wrench-Spark Plug                                                                                                                          | 617                                                                                                        | 270344S  | Seal-O Ring<br>(Intake Manifold)                                                                                                                                    |
|          |          |                                                                                                                                                                           | 390      | 691839   | Spring-Choke<br>Diaphragm                                                                                                                  | 621                                                                                                        | 692310   | Switch-Stop                                                                                                                                                         |
|          |          |                                                                                                                                                                           | 393      | 691837   | Screen-Carburetor                                                                                                                          | 633                                                                                                        | 691321   | Seal-Choke/Throttle<br>Shaft<br>(Throttle)                                                                                                                          |
|          |          |                                                                                                                                                                           | 394      | 795083   | Diaphragm-Carburetor                                                                                                                       | 635                                                                                                        | 66538S   | Boot-Spark Plug<br>Used on Type No(s).<br>0113, 0117, 0124,<br>0130, 0131, 0498,<br>0735, 0808, 0857,<br>0870, 0934, 3735,<br>3808, 3857.                           |
|          |          |                                                                                                                                                                           | 426      | 691107   | Screw<br>(Governor Blade)                                                                                                                  |                                                                                                            |          |                                                                                                                                                                     |
|          |          |                                                                                                                                                                           | 455      | 691236   | Cup-Flywheel                                                                                                                               |                                                                                                            |          |                                                                                                                                                                     |
|          |          |                                                                                                                                                                           | 456      | 692299   | Plate-Pawl Friction                                                                                                                        |                                                                                                            |          |                                                                                                                                                                     |

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.  
3756-8 Assemblies include all parts shown in frames. 07/13/2010



| REF. NO. | PART NO. | DESCRIPTION                                                                                                                          | REF. NO. | PART NO. | DESCRIPTION                                                                                                                                                             | REF. NO. | PART NO. | DESCRIPTION                                                                                                                                                                                                                                |
|----------|----------|--------------------------------------------------------------------------------------------------------------------------------------|----------|----------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------|----------|----------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 668      | 692889   | Spacer                                                                                                                               | 836A     | 790745   | Screw<br>(Muffler Guard)<br>(1/2" Long)<br>Used on Type No(s).<br>0127, 0944, 1074.                                                                                     | 957B     | 792878   | Cap-Fuel Tank                                                                                                                                                                                                                              |
| 670      | 691633   | Spacer-Fuel Tank                                                                                                                     |          |          |                                                                                                                                                                         | 969      | 799013   | Screw<br>(Blower Housing<br>Cover)<br>Used on Type No(s).<br>0735.                                                                                                                                                                         |
| 676D     | 397931   | Deflector-Muffler<br>Used on Type No(s).<br>0113, 0130, 0131.                                                                        | 836B     | 691125   | Screw<br>(Muffler Guard)<br>(5/8" Long)<br>Used on Type No(s).<br>0944, 1074.                                                                                           | 969A     | 799014   | Screw<br>(Blower Housing<br>Cover)<br>(Used After Code Date<br>10061300)<br>Used on Type No(s).<br>0113, 0117, 0123,<br>0124, 0127, 0130,<br>0131, 0498, 0808,<br>0843E1, 0857E1,<br>0870, 0874, 0934,<br>0944, 1074, 3808,<br>3843, 3857. |
| 677      | 690661   | Screw<br>(Muffler Deflector)<br>Used on Type No(s).<br>0113, 0130, 0131.                                                             | 842      | 691870   | Seal-O Ring<br>(Dipstick Tube)                                                                                                                                          |          |          |                                                                                                                                                                                                                                            |
| 689      | 691855   | Spring-Friction                                                                                                                      | 847      | 691440   | Dipstick/Tube<br>Assembly                                                                                                                                               |          |          |                                                                                                                                                                                                                                            |
| 718      | 690959   | Pin-Locating<br>(Cylinder)                                                                                                           | 851      | 493880S  | Terminal-Spark Plug                                                                                                                                                     |          |          |                                                                                                                                                                                                                                            |
| 718A     | 499047   | Pin-Locating<br>(Crankshaft)<br>(Used Before Code<br>Date 08071400).                                                                 | 851A     | 692424   | Terminal-Spark Plug                                                                                                                                                     |          |          |                                                                                                                                                                                                                                            |
| 724      | 697478   | Retainer-Seal                                                                                                                        | 868      | 697338   | Seal-Valve<br>(Exhaust)                                                                                                                                                 |          |          |                                                                                                                                                                                                                                            |
| 729      | 690586   | Clip-Wire                                                                                                                            | 869      | 699641   | Seat-Valve<br>(Intake)                                                                                                                                                  |          |          |                                                                                                                                                                                                                                            |
| 741      | 796210   | Gear-Timing<br>(Used After Code Date<br>08071300).<br>----- Note -----<br>691805 Gear-Timing<br>(Used Before Code<br>Date 08071400). | 870      | 699642   | Seat-Valve<br>(Exhaust)                                                                                                                                                 |          |          |                                                                                                                                                                                                                                            |
| 745      | 691146   | Screw<br>(Brake)<br>(7/8" Long)                                                                                                      | 871      | 699643   | Bushing-Valve Guide<br>(Exhaust)<br>----- Note -----<br>63709 Bushing-Valve<br>Guide<br>(Intake)                                                                        |          |          |                                                                                                                                                                                                                                            |
| 745A     | 690859   | Screw<br>(Brake)<br>(1/2" Long)                                                                                                      | 913      | 494409   | Seat-Check Valve                                                                                                                                                        |          |          |                                                                                                                                                                                                                                            |
| 772      | 691111   | Screw<br>(Linkage Cover)<br>Used on Type No(s).<br>0735.                                                                             | 921      | 699796   | Cover-Blower Housing<br>Used on Type No(s).<br>0735.                                                                                                                    |          |          |                                                                                                                                                                                                                                            |
| 832      | 699299   | Guard-Muffler<br>(Super Lo Tone)<br>Used on Type No(s).<br>0870.                                                                     | 921A     | 793973   | Cover-Blower Housing<br>Used on Type No(s).<br>0113, 0117, 0123,<br>0124, 0127, 0498,<br>0808, 0843E1,<br>0857E1, 0870, 0874,<br>0934, 0944, 1074,<br>3808, 3843, 3857. | 976      | 694394   | Primer-Carburetor                                                                                                                                                                                                                          |
| 832A     | 699670   | Guard-Muffler<br>(Round Lo Tone)<br>Used on Type No(s).<br>0114, 0123, 0498.                                                         | 921C     | 792273   | Cover-Blower Housing<br>Used on Type No(s).<br>0130, 0131.                                                                                                              | 994      | 792245   | Arrester-Spark<br>Used on Type No(s).<br>1074.                                                                                                                                                                                             |
| 832C     | 790743   | Guard-Muffler<br>Used on Type No(s).<br>0944, 1074.                                                                                  | 922      | 692135   | Spring-Brake                                                                                                                                                            | 1036     |          | Label-Emissions<br>(Available From A<br>Briggs & Stratton<br>Authorized Dealer)                                                                                                                                                            |
| 832D     | 790744   | Guard-Muffler<br>Used on Type No(s).<br>0127.                                                                                        | 923      | 691487   | Brake                                                                                                                                                                   | 1058     | 277038   | Operator's Manual                                                                                                                                                                                                                          |
| 836      | 690664   | Screw<br>(Muffler Guard)<br>(13/32" Long)<br>Used on Type No(s).<br>0114, 0123, 498, 0870.                                           | 925      | 691349   | Cover-Linkage<br>Used on Type No(s).<br>0735.                                                                                                                           | 1095     | 498526   | Gasket Set-Valve                                                                                                                                                                                                                           |
|          |          |                                                                                                                                      | 957      | 497929S  | Cap-Fuel Tank                                                                                                                                                           | 1210     | 499901   | Pulley/Spring<br>Assembly<br>(Pulley)                                                                                                                                                                                                      |
|          |          |                                                                                                                                      | 957A     | 791129   | Cap-Fuel Tank<br>Used on Type No(s).<br>0123, 0124, 0127.                                                                                                               | 1211     | 499901   | Pulley/Spring<br>Assembly<br>(Spring)                                                                                                                                                                                                      |
|          |          |                                                                                                                                      |          |          |                                                                                                                                                                         | 1319     | 794467   | Label-Warning                                                                                                                                                                                                                              |
|          |          |                                                                                                                                      |          |          |                                                                                                                                                                         | 1330     | 270962   | Repair Manual                                                                                                                                                                                                                              |

*Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.*  
**3756-9** **Assemblies include all parts shown in frames.** **07/13/2010**

Not for  
Reproduction

Not for  
Reproduction

Not for  
Reproduction

