



Illustrated Parts List

Model Series

12R600

TYPE NUMBERS
0110 through 0117.

TABLE OF CONTENTS

Air Cleaner	6
Blower Housing/Shrouds	7
Camshaft	2
Carburetor	4
Controls	5
Crankshaft	2
Cylinder	2
Cylinder Head	3
Electric Starter	7
Engine Sump	2
Exhaust System	6
Flywheel	7
Fuel Supply	4
Governor Spring	5
Ignition	5
Kits/Gaskets Sets	8
Lubrication	2
Piston Group	2
Rewind Starter	7

Not for production



PRINTED IN U.S.A.


COPYRIGHT by BRIGGS & STRATTON CORPORATION
All rights reserved. No part of this material may be reproduced or transmitted, in any form or by any means, electronic or mechanical, including photocopying, recording or by any information storage and retrieval system, without permission in writing from Briggs & Stratton Corporation.

12R600




1319 WARNING LABEL



REQUIRED when replacing parts with warning labels affixed.











Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 4162-2 Assemblies include all parts shown in frames. 11/18/2008



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 4162-3 Assemblies include all parts shown in frames. 11/18/2008








Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
4162-4 Assemblies include all parts shown in frames. 11/18/2008






Not for
Reproduction



12R600







Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
4162-6 Assemblies include all parts shown in frames. 11/18/2008



1036 EMISSIONS LABEL



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.
 4162-7 Assemblies include all parts shown in frames. 11/18/2008



Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
1	697893	Cylinder Assembly	26	795431	Ring Set (Standard)	117	498981	Jet–Main (Standard)
2	399269	Kit–Bushing/Seal (Magneto Side)			----- Note -----	118	497466	Jet–Main (High Altitude)
3	★299819S	Seal–Oil (Magneto Side)			795432 Ring Set (.020" Oversize)	121	792383	Kit–Carburetor Overhaul
4	493279	Sump–Engine	27	691866	Lock–Piston Pin	122★♦♦△692799		Spacer–Carburetor
5	795501	Head–Cylinder	28	499423	Pin–Piston	122A	792382	Spacer–Carburetor
7	★△697230	Gasket–Cylinder Head	29	499424	Rod–Connecting	125	790120	Carburetor (Primer System)
8	495786	Breather Assembly	32	691664	Screw (Connecting Rod)	127	●694468	Plug–Welch
9	★699833	Gasket–Breather	32A	695759	Screw (Connecting Rod)	130	691203	Valve–Throttle ----- Note -----
10	691125	Screw (Breather Assembly)	33	499642	Valve–Exhaust			696564 Valve–Throttle (Used With Plastic Throttle Shaft)
11A	691781	Tube–Breather	34	499641	Valve–Intake	133	398187	Float–Carburetor
12	★692232	Gasket–Crankcase	35	691304	Spring–Valve (Intake)	134	●398188	Kit–Needle/Seat
13	691137	Screw (Cylinder Head)	36	691304	Spring–Valve (Exhaust)	137	●●693981	Gasket–Float Bowl
15	691680	Plug–Oil Drain (Square Socket)	37	694086	Guard–Flywheel	146	690979	Key–Timing
16	691457	Crankshaft Used on Type No(s). 0110, 0115. ----- Note -----	40	692194	Retainer–Valve	163♦♦●691894		Gasket–Air Cleaner
		692823 Crankshaft Used on Type No(s). 0116, 0117.	43	691997	Slinger–Governor/Oil	163A♦♦●692667		Gasket–Air Cleaner
			45	690977	Tappet–Valve	187	791766	Line–Fuel (Cut to Required Length)
			46	694039	Camshaft	188	691147	Screw (Control Bracket)
			51★♦♦△692668		Gasket–Intake	190	690940	Screw (Fuel Tank)
20	★399781S	Seal–Oil (PTO Side)	51A★♦♦△697735		Gasket–Intake	192	694543	Adjuster–Rocker Arm
22	691092	Screw (Crankcase Cover/ Sump)	51B★♦♦△692555		Gasket–Intake	202	691303	Link–Mechanical Governor
23	699488	Flywheel Used on Type No(s). 0115, 0117. ----- Note -----	55	691421	Housing–Rewind Starter	209	691290	Spring–Governor
		692693 Flywheel Used on Type No(s). 0110, 0116.	58	697316	Rope–Starter (Cut To Required Length)	211	692434	Spring–Governed Idle
24	222698S	Key–Flywheel	60	281434S	Grip–Starter Rope	216	793655	Link–Choke
25	795429	Piston Assembly (Standard) ----- Note -----	65	690837	Screw (Rewind Starter)	222H	792397	Bracket–Control Used on Type No(s). 0110, 0115, 0116, 0117.
		795430 Piston Assembly (.020" Oversize)	78	691108	Screw (Flywheel Guard)	227	691467	Lever–Governor Control
			95	691636	Screw (Throttle Valve)	238	691300	Cap–Valve
			97	499682	Shaft–Throttle (Metal)	240	298090S	Filter–Fuel
					----- Note -----	259	691189	Bracket–Casing Clamp
			104	●691242	Pin–Float Hinge			
					790121 Shaft–Throttle (Plastic)			

★ Included in Engine Gasket Set–Ref. No.358.

● Included in Carburetor Overhaul Kit–Ref. No. 121.

♦ Included in Carburetor Gasket Set–Ref. No. 977.

△ Included in Valve Gasket Set–Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

12R600

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
265	690798	Clamp-Casing	425A	690244	Screw (Air Cleaner Cover)	619	691108	Screw (Cylinder Head Plate)
267	691044	Screw (Casing Clamp)	443B	690255	Screw (Air Cleaner Primer Base)	621	692310	Switch-Stop
268	691025	Casing-Control Wire (Cut To Required Length)	445A	697029	Filter-Air Cleaner Cartridge	633	◆◆691321	Seal-Choke/Throttle Shaft
269	691026	Wire-Control (Cut To Required Length)	455	791960	Cup-Flywheel	633A◆◆691321		Seal-Choke/Throttle Shaft
270	691027	Nut (Control Wire Casing)	456	692299	Plate-Pawl Friction	635	66538S	Boot-Spark Plug
271	691028	Lever-Control	459	281505S	Ratchet-Pawl	651	691660	Screw (Starter Gear Cover)
276	◆271716	Washer-Sealing	505	691251	Nut (Governor Control Lever)	670	692294	Spacer-Fuel Tank
287	690940	Screw (Dipstick Tube)	510	795093	Drive-Starter	676B	396548	Deflector-Muffler
300	697590	Muffler-Exhaust	513	692358	Clutch-Drive	676C	497682	Deflector-Muffler
304	499676	Housing-Blower	523	499621	Dipstick	677	690661	Screw (Muffler Deflector)
305	691108	Screw (Blower Housing)	524	★692296	Seal-Dipstick Tube	684	690345	Screw (Breather Passage Cover)
306	691232	Shield-Cylinder	525	495265	Tube-Dipstick	689	691855	Spring-Friction
307	690345	Screw (Cylinder Shield)	529	692937	Grommet (Starter Motor)	697	691127	Screw (Drive Cap)
309A	795092	Motor-Starter	562	691119	Bolt (Governor-Control Lever)	718	690959	Pin-Locating
332	690662	Nut (Flywheel)	578	398153	Wire Assembly	741	794388	Gear-Timing (Use Without Woodruff Key)
333	802574	Armature-Magneto	584	697734	Cover-Breather Passage			(Used After Code Date 07093000). ----- Note -----
334	691061	Screw (Magneto Armature)	585	★691879	Gasket-Breather Passage			790345 Gear-Timing (Use Without Woodruff Key)
337	692051	Plug-Spark (Resistor)	592	690800	Nut (Rewind Starter)			(Used Before Code Date 07100100).
		----- Note -----	597	691696	Screw (Pawl Friction Plate)			691830 Gear-Timing (Uses Woodruff Key)
		692720 Plug-Spark (EMS)	601	791850	Clamp-Hose	742	93941	Retainer-E-Ring
339	795146	Tube/Connector Assembly	608	497680	Starter-Rewind	783	691918	Gear-Pinion
356	692390	Wire-Stop	613	691108	Screw (Muffler)	783A	691269	Gear-Pinion
358	792384	Gasket Set-Engine	615	690340	Retainer-Governor Shaft	784	795095	Cover-Starter Gear
363	19069	Puller-Flywheel	616	698801	Crank-Governor	785	692352	Gasket-Starter Cover
365	691129	Screw (Carburetor)				789A	792685	Harness-Wiring
383	19374S	Wrench-Spark Plug				830	694544	Stud-Rocker Arm
404	690272	Washer (Governor Crank)				832	691466	Guard-Muffler

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION	REF. NO.	PART NO.	DESCRIPTION
836	691147	Screw (Muffler Guard)	946	396526	Guide-Rope	1023	499624	Cover-Rocker Arm
836A	697551	Screw (Muffler Guard)	957C	794793	Cap-Fuel Tank (Plastic)	1026	692045	Rod-Push
842	★691031	Seal-O Ring (Dipstick Tube)	966B	795151	Base-Air Cleaner Primer	1029	691230	Arm-Rocker
843	691884	Sleeve-Lever	967A	273356S	Filter-Pre Cleaner	1034	691343	Guide-Push Rod
847	692047	Dipstick/Tube Assembly	968E	795147	Cover-Air Cleaner	1036		Label-Emissions (Available From A Briggs & Statton Authorized Dealer)
851	493880S	Terminal-Spark Plug	969	691138	Screw (Blower Housing Cover)	1058	277102	Operator's Manual
853	696842	Adaptor-Wire	972C	794792	Tank-Fuel (Plastic)	1059	692311	Kit-Screw/Washer
868	★△692044	Seal-Valve	975	493640	Bowl-Float	1095	792386	Gasket Set-Valve
883	★△691893	Gasket-Exhaust	976	694395	Primer-Carburetor	1210	498144	Pulley/Spring Assembly (Pulley)
886	696268	Gasket Set-Cylinder Head/Plate	977	792385	Gasket Set-Carburetor	1211	498144	Pulley/Spring Assembly (Spring)
914	691108	Screw (Rocker Cover)	993	★△694088	Gasket-Cylinder Head Plate	1319	794467	Label-Warning
921E	795145	Cover-Blower Housing	1005	691346	Fan-Flywheel	1330	272147	Manual-Repair
937	691325	Spline-Starter	1022	★△691890	Gasket-Rocker Cover			

★ Included in Engine Gasket Set-Ref. No.358.

● Included in Carburetor Overhaul Kit-Ref. No. 121.

◆ Included in Carburetor Gasket Set-Ref. No. 977.

△ Included in Valve Gasket Set-Ref. No 1095.

Illustrations cover a range of engines. Parts shown without corresponding text may not be used on your specific engine.

Not for
Reproduction

