

PP0100342 Insert

TECHNICAL DETAILS AND SPECIFICATIONS



| Engine | Honda GX160 |
|-------------------|-------------|
| Horsepower | 5.5 HP |
| RPM | 3600 |
| Displacement | 163 CC |
| Starting | Recoil |
| Total head | 95 Feet |
| Max delivery | 185 GPM |
| Suction diameter | 2" |
| Delivery diameter | 2" |
| Tank capacity | 1.0 Gallon |
| Net weight | 104 lbs |
| | |


IMPORTANT – Please make certain that persons who are to use this equipment thoroughly read and understand these instructions and any additional instructions provided prior to operation.

Pramac America, LLC

4970 Airport Road P. O. Box 6001 Kearney, NE 68847 1-800-445-1805

© 2009 Pramac America, LLC. All rights reserved. Powermate ® is a registered trademark of Pramac America, LLC.

PARTS DRAWING AND PARTS LIST - PP0100342



| REF. | PART | DESCRIPTION | QTY |
|------|--------|---------------------------|-----|
| NO. | NO. | | |
| 1 | | Pump Housing | 1 |
| 2 | | 25A Plug Set | 2 |
| 3 | | Cover Bolt | 1 |
| 4 | | Mechanical Seal | 1 |
| 5 | | Cushion Rubber | 4 |
| 6 | Note B | Screw SHC | 4 |
| 7 | Note B | Washer | 4 |
| 8 | | Delivery Housing | 1 |
| 9 | | Delivery Flange Packing | 1 |
| 10 | | 32A Plug Set | 1 |
| 11 | | Delivery Flange | 1 |
| 12 | | Head Packing | 1 |
| 13 | | Knob | 1 |
| 14 | | Casing Packing | 1 |
| 15 | | Front Cover Packing | 1 |
| 16 | | Impeller | 1 |
| 17 | | Front Cover | 1 |
| 18 | | O-Ring | 1 |
| 19 | | Volute Casing | 1 |
| 20 | | Suction Flange | 1 |
| 21 | | Check Valve Packing | 1 |
| 22 | | Seal Washer | 1 |
| 23 | | Base Set | 1 |
| 24 | Note B | Bolt HH | 1 |
| 25 | Note B | Bolt HH | 1 |
| 26 | Note B | Bolt HH | 1 |
| 27 | Note B | Bolt HH | 1 |
| 28 | Note B | Bolt HH | 1 |
| 29 | Note B | Screw SHC | 1 |
| 30 | Note B | Nut Hex | 1 |
| 31 | Note B | Nut Spring | 1 |
| 32 | | Impeller Adjusting Washer | 1 |
| 33 | Note A | Engine Honda GX160 | 1 |
| 34 | | Coupling Set | 1 |
| 35 | | Hose Band | 1 |
| 36 | | Strainer | 1 |
| 37 | Note B | Wing Bolt | 1 |
| 38 | | Wrench | 1 |
| 39 | | Nameplate | 1 |

Note A: Pramac America, LLC will not provide engines as replacement parts. Engines are covered through the engine manufacturer's warranty. Consult the accompanying engine manual or contact our service department for assistance. **Note B:** These are standard parts available at your local hardware store.